



INSTALLATION INSTRUCTIONS
FRONT DRESSER BAR
 For 1986-99 FLST
 Mfg. p/n 190035
 (See pkg. label for Dist. p/n)

ATTENTION INSTALLER (if other than owner):
 Please forward this instruction sheet and the warranty card to the purchaser of this product. These instructions also contain valuable information necessary to the end user.

INTRODUCTION:
 These instructions describe the procedure for properly installing KHROME WERKS® Front Dresser Bar onto 1986-99 H-D FLST models. Review instructions carefully before beginning, as they contain important information. Please retain for future reference.

Particularly important information is distinguished in these instructions by the following notations:

NOTE: A NOTE provides key information to make procedures easier or clearer.

CAUTION: A CAUTION indicates special procedures that must be followed to avoid damage to the motorcycle or accessories.

WARNING: A WARNING indicates special procedures that must be followed to avoid injury or death to a motorcycle operator or person inspecting or repairing the motorcycle.

TOOLS REQUIRED:

- 2 . 9/16+combination wrenches
- 2 . 1/2+combination wrenches
- 1 . 3/16+socket wrench
- 1 . 5/16+socket wrench

BILL OF MATERIALS

Item #	Mfg. P/N	Description	Qty.
1	190036	Dresser Bar	1
2	190037	Reinforcement bracket	1
3	420448	Screw, 5/16+24 x 1 1/4+hex	1
4	420302	Washer, .33 x .75 x 1/8+	1
5	420070	Nut, 5/16+24 prev. torque	1
6	420510	Screw, 3/8+16 x 1 3/4+hex	1
7	420488	Screw, 3/8+24 x 1 1/4+hex	1
8	420068	Nut, 3/8+24 biway	1

PROCEDURE:

CAUTION:
 Dresser Bars are designed for aesthetics only. They may provide a very small amount of protection for motorcycle in the event of a tip-over while it is parked or at a very low speed. They are not intended to provide bodily protection in any circumstances.

1. Remove hardware securing front mount on left driver floorboard. Save lock washer and discard bolt and flat washer.
2. Install top mount of dresser bar to cross brace located just below frame neck. Install 5/16+x 1 1/4+hex screw with thick washer (items 3, 4) through Dresser Bar and into cross brace. Install reinforcement bracket and lock nut (items 2, 5) behind cross brace. Finger tighten.

NOTE: Reinforcement bracket has a mounting tab. This tab points down and is provided as an oil cooler mount if desired.

WARNING:
 When mounting any oil cooler, check for clearance on the front fender by completely collapsing the front end with oil cooler installed. Be careful so you don't damage front fender.

3. Position left side mounting tab to inside of footboard mounting plate. Install 3/8+ x 1 3/4+ screw (item 6) with OEM lock washer through lower left Dresser Bar mount, and into floorboard pivot. Finger tighten.
4. Position Dresser Bar mount to outside of right floorboard mount. Install 3/8+ x 1 1/4+ screw (item 7) through Dresser Bar mount and hole in lower front corner of right floorboard mount. Install 3/8+24 nut (item 8). Finger tighten.

5. Align Dresser Bar and tighten all hardware. Periodically check this hardware for tightness.

USE AND CARE: Wash your accessories with the same care you use when washing your motorcycle. Use mild soap and water. DO NOT use abrasive chemicals or cleaners, or high pressure washers.

KHROME WERKS®
P.O. BOX 355 • New Prague, MN 56071