



**INSTALLATION INSTRUCTIONS
KICKSTAND STOP for BIG TWINS**

Mfg. p/n 240210
(See pkg. label for Dist. p/n)

ATTENTION INSTALLER (if other than owner):

Please forward this instruction sheet and the warranty card to the purchaser of this product. These instructions also contain valuable information necessary to the end user.

INTRODUCTION:

These instructions describe the procedure for properly installing KHROME WERKS® KICKSTAND STOP on 1958-84 FL and FX models with stock leg bracket #50014-74 (not FXWG) and 1989-99 Softails with OEM leg bracket #50018-85. Review instructions carefully before beginning, as they contain important information. Please retain for future reference.

Particularly important information is distinguished in these instructions by the following notations:

NOTE: A NOTE provides key information to make procedures easier or clearer.

CAUTION: A CAUTION indicates special procedures that must be followed to avoid damage to the motorcycle or accessories.

WARNING: A WARNING indicates special procedures that must be followed to avoid injury or death to a motorcycle operator or person inspecting or repairing the motorcycle.

TOOLS REQUIRED:

- 1 . 5/8+socket
- 1 . 3/32+hex key wrench
- 1 . 1/2+socket
- 1 . torque wrench

PROCEDURE:

1. Jack up bike off kickstand and secure so it will not fall over.
2. Remove nut/screw and hardware on top of kickstand leg, then the leg stop; note orientation of leg stop. Discard stop and save hardware.
3. Install new Kickstand Stop in same position as removed piece. Install 10-32 set screw into new Kickstand Stop so that nylon end will contact kickstand bracket when folded up. Carefully fold up kickstand leg and adjust set screw to contact bracket and leave small gap (1/16") between leg and primary cover. Install nut on socket end of set screw and tighten. Install hardware removed in Step 2 and tighten nut to 55 ft. lbs. and screw to 20 ft. lbs.
4. Check fit and clearance after tightening; adjust if necessary.

USE AND CARE: Wash your accessories with the same care you use when washing your motorcycle. Use mild soap and water. DO NOT use abrasive chemicals or cleaners, or high pressure washers.

KHROME WERKS®

P.O. BOX 355 • New Prague, MN 56071

Revised November 2009

Page 1 of 1



**INSTALLATION INSTRUCTIONS
KICKSTAND STOP for BIG TWINS**

Mfg. p/n 240210
(See pkg. label for Dist. p/n)

ATTENTION INSTALLER (if other than owner):

Please forward this instruction sheet and the warranty card to the purchaser of this product. These instructions also contain valuable information necessary to the end user.

INTRODUCTION:

These instructions describe the procedure for properly installing KHROME WERKS® KICKSTAND STOP on 1958-84 FL and FX models with stock leg bracket #50014-74 (not FXWG) and 1989-99 Softails with OEM leg bracket #50018-85. Review instructions carefully before beginning, as they contain important information. Please retain for future reference.

Particularly important information is distinguished in these instructions by the following notations:

NOTE: A NOTE provides key information to make procedures easier or clearer.

CAUTION: A CAUTION indicates special procedures that must be followed to avoid damage to the motorcycle or accessories.

WARNING: A WARNING indicates special procedures that must be followed to avoid injury or death to a motorcycle operator or person inspecting or repairing the motorcycle.

TOOLS REQUIRED:

- 1 . 5/8+socket
- 1 . 3/32+hex key wrench
- 1 . 1/2+socket
- 1 . torque wrench

PROCEDURE:

1. Jack up bike off kickstand and secure so it will not fall over.
2. Remove nut/screw and hardware on top of kickstand leg, then the leg stop; note orientation of leg stop. Discard stop and save hardware.
3. Install new Kickstand Stop in same position as removed piece. Install 10-32 set screw into new Kickstand Stop so that nylon end will contact kickstand bracket when folded up. Carefully fold up kickstand leg and adjust set screw to contact bracket and leave small gap (1/16") between leg and primary cover. Install nut on socket end of set screw and tighten. Install hardware removed in Step 2 and tighten nut to 55 ft. lbs. and screw to 20 ft. lbs.
4. Check fit and clearance after tightening; adjust if necessary.

USE AND CARE: Wash your accessories with the same care you use when washing your motorcycle. Use mild soap and water. DO NOT use abrasive chemicals or cleaners, or high pressure washers.

KHROME WERKS®

P.O. BOX 355 • New Prague, MN 56071

Revised November 2009

Page 1 of 1