



INSTALLATION INSTRUCTIONS
3.5" HP-PLUS® MUFFLERS
FOR 1995-UP FL & TOURING MODELS
Mfg. p/n 202285, 202290, 202295
(See pkg. label for Dist. p/n)

ATTENTION INSTALLER (if other than owner):

Please forward this instruction sheet and the warranty card to the purchaser of this product. These instructions also contain valuable information necessary to the end user.

INTRODUCTION:

These instructions describe the procedure for properly installing KHROME WERKS® 3.5+HP-Plus® Taper, Slant back or Slash Mufflers on 1995-up Harley-Davidson FL and Road King® models: Evos and Twin Cam 88® and 96®, stock or bored and/or stroked, carbureted or fuel-injected (stock through Stage III). Review instructions carefully before beginning, as they contain important information. Please retain for future reference.

Particularly important information is distinguished in these instructions by the following notations:

NOTE: A NOTE provides key information to make procedures easier or clearer.

CAUTION: A CAUTION indicates special procedures that must be followed to avoid damage to the motorcycle or accessories.

WARNING: A WARNING indicates special procedures that must be followed to avoid injury or death to a motorcycle operator or person inspecting or repairing the motorcycle.

TOOLS REQUIRED:

- 1 . 1/2" combination wrench
- 1 . 9/16" combination wrench

PROCEDURE:

1. Remove saddlebags from bike.
2. Note position of muffler clamp mounting bolt on each muffler. Loosen muffler clamps on each side and slide forward.

NOTE: To ensure sealing integrity of muffler clamps, and prevent the possibility of leakage, Harley-Davidson recommends that the muffler clamp assemblies be discarded and replaced each time they are removed.

CAUTION: If muffler clamps are being reused, apply anti-seize compound to the threads to ensure proper clamping.

3. Remove two 5/16" bolts and washers from rear brackets on each side and save. Slide old mufflers off header pipes. Remove muffler clamps. Discard old mufflers.

4. Install new clamps on the HP-Plus® mufflers in the same position as the original clamps.

5. Slide mufflers onto header pipes into same position as original mufflers. The rear brackets on the mufflers should be positioned halfway between the rubber mounts on the saddlebag/muffler supports. If muffler-to-header fit is loose, use silicone to seal. Install 5/16" + 18 bolts and washers removed in step 3 and tighten.

6. Position and orient the muffler clamps in the original position, making sure the clamps cover the rear edge of the clamping slots, and tighten.

NOTE: When tightening the clamps make sure the muffler doesn't rotate on the header pipe. Maintain proper alignment.

7. Before operating motorcycle, clean pipes and mufflers with soap and water or window cleaner. Dry thoroughly. Also check all hardware to be sure it is tight. Install muffler heat shields, if purchased.

8. Reinstall saddlebags.

WARNING: Check all mounting hardware to be sure it is tight before and after first operation of motorcycle. Periodically, check tightness of all mounting hardware.

CAUTION: Carefully read the enclosed Important Notice sheet. Re-jetting and or recalibration may be required.

USE AND CARE: Wash your accessories with the same care you use when washing your motorcycle. Use mild soap and water. DO NOT use abrasive chemicals or cleaners, or high pressure washers.

CAUTION: Cover ends of mufflers when washing motorcycle. Mufflers may internally corrode if saturated with water and allowed to sit. (No warranty.) Avoid starting and stopping engine without riding sufficient miles to eliminate corrosive moisture from the exhaust system.

NOTE: These mufflers are designed for use on close course competition motorcycles only and do not conform to U.S. EPA noise emission standards. These mufflers are not replacements for motorcycles equipped with factory installed catalytic converter style mufflers.

KHROME WERKS®
P.O. BOX 355 • New Prague, MN 56071