



INSTALLATION INSTRUCTIONS
SADDLEBAG SUPPORTS
For 2006-10 DYNA® WIDE GLIDE®
And 2008-10 DYNA® FAT BOB® models
Mfg. p/n 110835
(See pkg. label for Dist. p/n)

ATTENTION INSTALLER (if other than owner):
Please forward this instruction sheet and the warranty card to the purchaser of this product. These instructions also contain valuable information necessary to the end user.

INTRODUCTION:
These instructions describe the procedure for properly installing KHROME WERKS® Saddlebag Supports on 2006-10 Dyna® Wide Glide® or 2008-10 Dyna® Fat Bob® models. Review instructions carefully before beginning, as they contain important information. Please retain for future reference.

Particularly important information is distinguished in these instructions by the following notations:

NOTE: A NOTE provides key information to make procedures easier or clearer.

CAUTION: A CAUTION indicates special procedures that must be followed to avoid damage to the motorcycle or accessories.

WARNING: A WARNING indicates special procedures that must be followed to avoid injury or death to a motorcycle operator or person inspecting or repairing the motorcycle.

- TOOLS REQUIRED:**
- 1 . #45 Torx 3/8+drive socket and 3/8+driver
 - 1 . 5/16+hex key 3/8+drive socket
 - 1 . 3/8+drive torque wrench
 - 1 . #243 Loctite thread lock

PROCEDURE:

NOTE: Remove sissy bar upright (if installed) for easier installation.

1. Remove and discard the OEM 3/8+16 x 1.0+Torx screws at the front and rear of the chrome fender support cover just ahead of the directional signal. A wrench inside the fender well is not required; these screws thread into a nut plate inside the fender. Perform one side at a time.
2. Apply blue Loctite 243 to the threads of the supplied 3/8+16 socket head cap screws and insert them through the bosses of the KW support, fender support cover, frame strut, sissy bar side plate, fender and into the fender mounting plate.
3. Torque all fasteners to 20-27 ft-lbs. within 10 minutes of applying Loctite.
4. Repeat for other side.

WARNING: Saddlebags must be secured to the supports with straps supplied by saddlebag manufacturer. Upon initial installation ensure that no parts of the bags or the mounting straps could interfere with operation of rear belt (or chain), shocks or wheels. We recommend throw-over saddlebags be mounted securely under the seat (not thrown over it). Periodically check straps to ensure proper installation.

USE AND CARE: Wash your accessories with the same care you use when washing your motorcycle. Use mild soap and water. DO NOT use abrasive chemicals or cleaners, or high pressure washers.

BILL OF MATERIALS

Item #	Mfg. p/n	Description	Qty.
1	110836	Saddlebag Support, Left	1
	110837	Saddlebag Support, Right	1
2	430522	Screw, skt 3/8+16 x 1 1/2"	4

KHROME WERKS®
P.O. BOX 355 • New Prague, MN 56071