



INSTALLATION INSTRUCTIONS

SADDLEBAG SUPPORTS

For 1982-94 FXR

Mfg. p/n 110859A

(See pkg. label for Dist. p/n)

ATTENTION INSTALLER (if other than owner):

Please forward this instruction sheet and the warranty card to the purchaser of this product. These instructions also contain valuable information necessary to the end user.

INTRODUCTION:

These instructions describe the procedure for properly installing KHROME WERKS® Soft Saddlebag Supports onto 1982-94 FXR models. Review instructions carefully before beginning, as they contain important information. Please retain for future reference.

Particularly important information is distinguished in these instructions by the following notations:

NOTE: A NOTE provides key information to make procedures easier or clearer.

CAUTION: A CAUTION indicates special procedures that must be followed to avoid damage to the motorcycle or accessories.

WARNING: A WARNING indicates special procedures that must be followed to avoid injury or death to a motorcycle operator or person inspecting or repairing the motorcycle.

TOOLS REQUIRED:

- 2 . 9/16+combination wrenches

BILL OF MATERIALS

Item#	Mfg. P/N	Description	Qty.
1	110861A	Saddlebag Support, left	1
	110862A	Saddlebag Support, right	1
2	420491	3/8+24 x 2+hex screw	2
3	420145	3/8+24 prevailing torque nut	4
4	420499	3/8+24 x 4 1/4+hex screw	2
5	420291	3/8+flat washer	2

PROCEDURE:

NOTE: Rear turn signals have to be moved in order to install soft saddlebags on 1982-86 FXR models, for two reasons. One is to allow room for saddlebags and the other is to provide rear mounting point for Supports. Rear mount has shortest sleeve attached.

1. Remove plastic plug from hole in frame gusset, located at rear of side cover. This hole is front mounting point for Support. Support front mount in end with longest sleeve attached.

2. On 1987 and later models, remove the strut bolt just to rear of upper shock mount. On 1982-86, if turn signal has already been removed, remove all hardware from turn signal mounting hole.

3. Attach front mount of Saddlebag Support (item 1) to frame gusset, using 3/8+x 2+screw and lock nut (items 2, 3). Start nut onto screw. Do not tighten.

4. Attach rear mount, using 3/8+x 3 1/4+screw and lock nut (items 3, 4). 1982-86 models will require a spacer between strut and rear mount. A washer (item 5) is supplied for that use.

5. Tighten all hardware.

6. Repeat for other side.

WARNING:

After both sides have been installed, clearance must be checked completely around Saddlebag Supports. This must be checked when shocks are extended, through complete travel and at full compression. Supports must not make contact with anything, especially any moving parts or brake components. Clearance must also be checked after saddlebags are installed.

Maximum recommended saddlebag load is seven pounds.

USE AND CARE: Wash your accessories with the same care you use when washing your motorcycle. Use mild soap and water. DO NOT use abrasive chemicals or cleaners, or high pressure washers.

KHROME WERKS®

P.O. BOX 355 • New Prague, MN 56071