



INSTALLATION INSTRUCTIONS
SISSY BAR SIDE STRAPS for 2006-08 FXDWG
and 2008-10 FXDF models
Mfg. p/n 263745
(See pkg. label for Dist. p/n)

ATTENTION INSTALLER (if other than owner): Please forward this instruction sheet and the warranty card to the purchaser of this product. These instructions also contain valuable information necessary to the end user.

INTRODUCTION:

These instructions describe the procedure for properly installing KHROME WERKS® Sissy Bar Side Straps on 2006-08 FXDWG Dyna® Wide Glide® and 2008-10 FXDF Dyna® Fat Bob® models. Review instructions carefully before beginning, as they contain important information. Please retain for future reference.

Particularly important information is distinguished in these instructions by the following notations:

NOTE: A NOTE provides key information to make procedures easier or clearer.

CAUTION: A CAUTION indicates special procedures that must be followed to avoid damage to the motorcycle or accessories.

WARNING: A WARNING indicates special procedures that must be followed to avoid injury or death to a motorcycle operator or person inspecting or repairing the motorcycle.

TOOLS REQUIRED:

- 1 . #45 Torx 3/8+drive socket and 3/8+driver
- 1 . 1/2" combination wrench
- 1 . 3/8+drive torque wrench
- 1 . #242 Loctite® thread lock
- 1 . Anti-seize thread lubricant
- 1 . 3/8+drive 5/32+Hex key socket

NOTE: For 2006-08 FXDWG use 8.75+wide uprights. For 2010 FXDF use 9.88+wide uprights. For 2008-09 FXDF use 9.56+wide uprights.

NOTE: To access the direction signal fastener, raise the motorcycle on a lift.

CAUTION: Buildup of chrome plating on fasteners may cause seizing or binding during installation. Use anti-seize lubricant on the 1/4+20 button head screws to prevent this.

1. Remove and save the OEM 3/8+16 x 1.00+Torx screws and washers securing the chrome fender support cover just ahead of the directional signal. A wrench inside the fender well is not required; this screw threads into a nut plate inside the fender. Perform one side at a time.
2. Support the directional assembly and remove the 5/16+hex head screw inside the fender. Save the screw and washer. Let the directional hang by the wire. The fender mounting plate will now be loose inside the fender and it will be reused. NOTE: If you are installing KW Sissy Bar Side Straps with KW Saddlebag Supports use the hardware and follow the instructions supplied with the Saddlebag Supports.
3. Slip KW side strap between the fender and the fender support. Align the holes in the side strap with the holes in the fender support and fender support cover. NOTE: The side straps are slotted to accommodate the directional wires.

CAUTION: Use care not to scratch paint during this step. We suggest using masking tape on the fender surface and to gently squeeze the fender inward while positioning side strap.

4. Apply blue Loctite® #242 to the threads of the OEM 3/8+16 x 1.00+Torx screws. Insert screws through the OEM washers, fender support cover, fender support, KW side strap, fender and into the fender mounting plate. Hand tighten at this time.
5. Apply blue Loctite #242 to the threads of the OEM 5/16+hex head screw and insert it through the OEM washer, fender mounting plate, fender, KW side plate, fender support cover from the inside of the fender and into the directional extension and housing.
6. Repeat for the other side.
7. Install the sissy bar upright (purchased separately . use only 8.75+size uprights) in the sockets of the side straps, using 1/4+20 button head screws with anti-seize applied to threads. Torque screws to 8-10 ft-lbs.
8. Torque fender support cover screws to 12-18 ft-lbs. Torque directional signal fastener to 12-16 ft-lbs. NOTE: Fasteners should be torqued within the minutes after applying Loctite® .
9. Test both directional lights for proper operation.

WARNING: Before operating motorcycle, check all hardware to be sure it is tight.

USE AND CARE: Wash your accessories with the same care you use when washing your motorcycle. Use mild soap and water. DO NOT use abrasive chemicals or cleaners, or high pressure washers.

BILL OF MATERIALS

Item#	Mfg. p/n	Description	Qty.
1	2637451	Side Strap, Left	1
	2637452	Side Strap, Right	1
2	433432	Screw, button head 1/4+20 x 3/4"	4

Suggested Khrome Werks® Uprights

- 263600 8.75+Lowboy Upright
- 263601 8.75+Mini Lowboy Upright
- 264170 8.75+Ultra Mini Lowboy Upright
- 263611 8.75+Round Upright
- 264190 8.75+Bantam Upright
- 264195 8.75+Rail Upright
- 263616 9.56+Round Upright
- 264154 9.56+Mini Lowboy Upright
- 263614 9.88+Round Upright
- 264155 9.88+Mini Lowboy Upright

KHROME WERKS®
P.O. BOX 355 • New Prague, MN 56071