



**INSTALLATION INSTRUCTIONS
SIDE STRAPS F/1994-2003 XLH
w/8 1/4" KHROME WERKS® SISSY BARS**
Mfg. p/n 264009B
(See pkg. label for Dist. p/n)

ATTENTION INSTALLER (if other than owner):

Please forward this instruction sheet and the warranty card to the purchaser of this product. These instructions also contain valuable information necessary to the end user.

INTRODUCTION:

These instructions describe the procedure for properly installing KHROME WERKS® Side Straps on 1994-2004 XLH models. Use only with KHROME WERKS® 8 1/4+Sissy Bars (P/Ns 264165, 264185, 263618, 264191, 264192, 264196). Review instructions carefully before beginning, as they contain important information. Please retain for future reference.

Particularly important information is distinguished in these instructions by the following notations:

NOTE: A NOTE provides key information to make procedures easier or clearer.

CAUTION: A CAUTION indicates special procedures that must be followed to avoid damage to the motorcycle or accessories.

WARNING: A WARNING indicates special procedures that must be followed to avoid injury or death to a motorcycle operator or person inspecting or repairing the motorcycle.

TOOLS REQUIRED:

- 1 . 3/16+hex key wrench
- 1 . 1/2+combination wrench
- 1 . 5/32+hex key wrench

Revised November 2009

KHROME WERKS®
P.O. BOX 355 • New Prague, MN 56071

Page 1 of 1

PROCEDURE:

1. Remove two button head socket screws and lock nuts that hold fender support to fender. Discard screws and save lock nuts.

NOTE: When installing new screws supplied, make sure that steel T-spacers inside of fender are still in rubber grommets before tightening.

2. Position Side Strap on fender support and insert supplied 5/16+18 x 1 3/8+button head screws through Side Strap and fender support. Use OEM lock nuts removed in step 1 on screws and tighten to 8-13 ft.-lbs.

3. Repeat for other side.

NOTE: The four 1/4+20 x 3/4+button head screws supplied are to be used when installing the sissy bar.

CAUTION: Buildup of chrome plating on fasteners may cause seizing or binding during installation. Use anti-seize lubricant on the 1/4+20 button head screws to prevent this.

USE AND CARE: Wash your accessories with the same care you use when washing your motorcycle. Use mild soap and water. DO NOT use abrasive chemicals or cleaners, or high pressure washers.



**INSTALLATION INSTRUCTIONS
SIDE STRAPS F/1994-2003 XLH
w/8 1/4" KHROME WERKS® SISSY BARS**
Mfg. p/n 264009B
(See pkg. label for Dist. p/n)

ATTENTION INSTALLER (if other than owner):

Please forward this instruction sheet and the warranty card to the purchaser of this product. These instructions also contain valuable information necessary to the end user.

INTRODUCTION:

These instructions describe the procedure for properly installing KHROME WERKS® Side Straps on 1994-2004 XLH models. Use only with KHROME WERKS® 8 1/4+Sissy Bars (P/Ns 264165, 264185, 263618, 264191, 264192, 264196). Review instructions carefully before beginning, as they contain important information. Please retain for future reference.

Particularly important information is distinguished in these instructions by the following notations:

NOTE: A NOTE provides key information to make procedures easier or clearer.

CAUTION: A CAUTION indicates special procedures that must be followed to avoid damage to the motorcycle or accessories.

WARNING: A WARNING indicates special procedures that must be followed to avoid injury or death to a motorcycle operator or person inspecting or repairing the motorcycle.

TOOLS REQUIRED:

- 1 . 3/16+hex key wrench
- 1 . 1/2+combination wrench
- 1 . 5/32+hex key wrench

Revised November 2009

KHROME WERKS®
P.O. BOX 355 • New Prague, MN 56071

Page 1 of 1

PROCEDURE:

1. Remove two button head socket screws and lock nuts that hold fender support to fender. Discard screws and save lock nuts.

NOTE: When installing new screws supplied, make sure that steel T-spacers inside of fender are still in rubber grommets before tightening.

2. Position Side Strap on fender support and insert supplied 5/16+18 x 1 3/8+button head screws through Side Strap and fender support. Use OEM lock nuts removed in step 1 on screws and tighten to 8-13 ft.-lbs.

3. Repeat for other side.

NOTE: The four 1/4+20 x 3/4+button head screws supplied are to be used when installing the sissy bar.

CAUTION: Buildup of chrome plating on fasteners may cause seizing or binding during installation. Use anti-seize lubricant on the 1/4+20 button head screws to prevent this.

USE AND CARE: Wash your accessories with the same care you use when washing your motorcycle. Use mild soap and water. DO NOT use abrasive chemicals or cleaners, or high pressure washers.